


To configure the Z-3080 Bar Code scanner to add an ENTER character after each scan, scan each of the following bar codes in order from top to bottom.



Start Configuration



Trailer



CR (Enter)



Set



End of Configuration



Start Configuration



Function Key Active ON



End of Configuration